

STICK &
SHOOT

Works with instax® INSTANT FILM

KONO!RAMA

TUTORIAL

ENGLISH

Match the pink corners and stick the adhesive strap on your KONO!RAMA layer.



1 KONO!RAMA
adhesive strap




2 KONO!RAMA
Layer



3 Your Instant film
cassette (not included)

Place the pink corner on the upper left corner of the film cassette and fold over the sticker.

Don't cover
the gap!



>> SHARE YOUR PHOTOS!
Find us on Instagram:
kono_the_reanimated_film

Ready to load your camera as usual.

**FOR BEST RESULTS:
USE ON SUNNY DAYS!**
Results may vary.



Watch our



Video tutorial

KONO!RAMA Layers are **REUSABLE**